

Installation Guide



STORAGE

Ultralon® Decking should be stored in a cool, dry, indoor location until installed on boat.

INSTALLATION LIMITATIONS - Do NOT install decking in temperatures below 10°C (50°F) or above 38°C (100°F) Do NOT attempt to remove or adjust placement once decking has adhered.

PREPARATION

Step 1: Thoroughly clean the surface area where decking will be applied using an alcohol based cleaner, such as Isopropylene.

Step 2: Make sure all grease, adhesive, mold-release, wax and other substances are removed before installing the product. The area must be completely dry before applying decking.

INSTALLATION

Step 1: Before you peel back the adhesive backing, place the decking on the application surface to check correct fit and spacing and determine the exact location of the decking.

Step 2: Turn decking over so that the adhesive backing is face up. With a sharp razor knife carefully cut the adhesive paper backing down the center at the shortest width. Be sure to completely cut through the backing paper WITHOUT cutting the decking.

Step 3: Now peel back and fold the four corners of the paper backing.

Step 4: Turn the decking back over and position it exactly where you want it installed.

Step 5: Using the 25mm/1-inch masking tape, tape one side of the decking in position on the application surface. Taping prevents the decking from moving while installing.

Step 6: Then carefully lift up the side that is not taped down and pull up the folded corners to loosen the adhesive backing.

Step 7: From the center working towards the outer edges, slowly and carefully peel the rest of the paper backing while applying the decking. Apply even pressure with a roller over the decking to ensure there's a firm bond between the decking and the surface area. DO NOT PULL OR STRETCH THE DECKING.

Step 7: Remove the masking tape from the other side of the decking and repeat step 7.

Step 9: The Pressure-Sensitive Adhesive (PSA) must be firmly rolled and pressed down on all surface areas and edges of the decking to ensure there is uniform adhesion.



www.dcdeckco.com.au