

Templating Guide



TEMPLATING YOUR BOAT:

- Materials Needed:
- Mylar Film, Clear builders plastic or similar transparent and flexible material
- Measuring tape
- Marker or pen
- Scissors or utility knife

Step 1: Prepare the Boat Deck Ensure that the boat deck is clean and free of debris. Remove any existing flooring or coverings that may interfere with the template process.

Step 2: Take the clear plastic and lay it flat over the boat deck and tape down. Use a measuring tape to measure the dimensions of the area where you will be installing the flooring. Be sure to measure accurately and account for any curves or contours in the boat deck and ensure each pad will fit within the sheet size purchased.

Step 4: Draw your desired shape onto the builders plastic using your marker. Using scissors or a utility knife, carefully cut the builders plastic according to the marker drawings, creating a template of the boat deck shape.

Step 5: Transfer the cut builders plastic template onto the U-Dek marine flooring material, aligning it with the edges and corners. Use a marker or pen to trace the template onto marine flooring material and transfer the shape accurately to ensure a precise fit.

Step 6: Cut the Marine Flooring Material Using a sharp utility knife or blade, carefully cut the marine flooring material along the traced lines to match the boat deck template. Take your time and make precise cuts for the best results.

Step 7: Place the cut marine flooring material onto the boat deck to test the fit. Make any necessary adjustments, such as trimming or shaping, to ensure a perfect fit. Take note of any areas that may require additional attention or adjustments.



www.dcdeckco.com.au